

1 GREEN
2 BLUE
3 RED
4 L.G. GREEN
5 B.T. BLACK
6 BLACK

TAPE ○



Phone 716-874-5301
Toll Free 800-342-3433
Innovative Concepts in
Entertainment Inc. Buffalo, NY

SION

3000 MODEL NO. 96206-3PC SERIAL NO.

115 V VAC 50/60 HZ 7.0 AMPS

Innovative Concepts in Entertainment Inc.

Buffalo, New York • (716) 833-0481 • (800) 342-3433 • Fax (716) 833-1342

NOTES

PUTTING CHALLENGE™

WARNING

This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference in which case the user at his own expense will be required to correct the interference.

NOTICE

PUTTING CHALLENGE is a trademark of GL Technology, Inc., Rolling Meadows, IL.

Entire contents of this manual copyright © 1991 Innovative Concepts in Entertainment Inc., Buffalo, New York. Revision #1 • (716) 833-0481 • (800) 342-3433 • Fax (716) 833-1342

Contents

Introduction.....	3
Game Description.....	3
Components and Controls.....	4
Game Installation.....	5
Game Testing.....	9
Playing the Game.....	12
Game Pricing.....	12
Adjusting Game Pricing.....	13
Adjusting the Ticket Dispenser.....	15
Accounting Mode.....	16
Using Accounting Mode.....	16
Maintenance Tips.....	18
Troubleshooting.....	19
Questions or Comments.....	21

KEYS FOR THE COIN DOOR ARE ATTACHED INSIDE THE PODIUM UNDER THE GREEN CONTROL PANEL NEXT TO THE CPU.

Introduction

Thanks for purchasing *PUTTING CHALLENGE*! Please read this manual thoroughly before attempting to assemble or operate your game. Failure to read the assembly instructions could lead to mistakes or game damage. If you don't read the instructions before assembly, you might also void your warranty.

Game Description

For the first time ever, a putting game achieves dramatic realism! *PUTTING CHALLENGE* utilizes a unique, flexible playfield surface. The game's computer adjusts this surface to simulate the contours of real golf greens. Inside the game, a series of unique, motorized actuator pistons can actually alter the playing surface. At computer command, these actuators raise or lower five critical sections of the playfield.

Every time you hit the ball during the game, the ball passes an optical sensor. This detects the ball in the play area. The game computer then expects the ball to go into the hole, roll off the playfield, or remain on the playfield. If the ball goes in the hole, a microswitch senses it. The game computer registers the score, and you'll hear a crowd cheering sound. If the ball rolls off the playfield, it rolls through the return system and rests in the ball ejector cup. Then the game registers points.

If the ball stops on the playfield, the computer recognizes that the ball didn't score. The game computer also senses that the ball didn't fall off the playfield. The game computer responds by altering the playfield surface until the ball rolls off. The game computer then displays the score. During that time, the surface may move to clear the ball. The ball may roll back to the player. If so, a speaker announces: "One-stroke penalty. Player, try again." Then the player must retake his turn.

Components and Controls

WARNING

To power this machine, use a grounded, three-prong outlet. You may not know if your outlet is properly grounded. In that case, please don't take chances! Instead, consult a qualified electrician. Failure to use a grounded outlet might cause personal injury or game damage. Furthermore use of non-grounded outlets may void your game's warranty. Also check the voltage rating on your machine. For safety and proper operation, this rating must match the voltage at your power outlet.

NOTICE

For this game, you need a level floor space of approximately six by eleven feet.

DESCRIPTION OF GAME COMPONENTS

MAIN CABINET

The main cabinet is the largest game component. It's the unit that the other components attach to. The main cabinet contains the playfield, cover glass and ball return system.

DISPLAY CABINET

The display cabinet contains the large, digital readout board. The small "hole number" PC board (on the graphics panel flag) also resides in the display cabinet. Also in the display cabinet, you'll find the power supply and lighting line outlet.

CONTROL CABINET

The control cabinet contains the GAME-SELECT, PLAYER-SELECT and HOLE-SELECT switches. Here you'll also find the CPU Board and coin door. Your control cabinet might include options too. These include a bill acceptor or ticket dispenser.

PLATFORM

For player convenience and safety, handrails attach to the platform. During gameplay, the player stands on the platform.

STEP

The step unit provides easy access to the platform.

CONTROL LOCATIONS

POWER ON-OFF

You can access this toggle switch from the outside of the game. You'll find POWER ON-OFF in a hole at the lower-right corner of the display cabinet.

TEST BUTTON

This button is on the CPU Board. This board resides in the control console, on a shelf underneath the control panel. Use the test button when you wish to check accounting totals or make adjustments to the game.

VOLUME CONTROL

The volume control is on the CPU Board in the control console.

OPERATOR CONTROLS

The GAME, PLAYER, and HOLE SELECT buttons on the control cabinet sometimes assume additional functions. This is the case during the Accounting and Diagnostics Modes. We'll discuss these modes later on.


Installation

When you assemble your machine, follow this procedure...

- [] 1. Unpack the components from their shipping containers. Identify what they are.
- [] 2. Place the main cabinet in a position on the floor close to its permanent position. Do this now, because the game will be difficult to move later on.
- [] 3. Get the parts package from the coinbox in the platform box. In the parts package, locate the allen wrench. Unscrew, and carefully remove the cover glass.
- [] 4. In the front of the cabinet on the playfield are two allen head bolts. These hold the playfield to the cabinet. Remove these screws and put them in a safe place. Lift the front of the playfield by grasping the ball return cover. Lift up. Temporarily prop up the playfield.
- [] 5. Locate the control cabinet. Use the same allen wrench to unscrew control panel screws on the front flange. Pull the control panel forward slightly. Lift up. The control panel has a channel on

its back edge. We've designed this channel for insertion onto the cabinet edge. While you install harnesses, use the channel to hold the panel up. You'll find that harness installation is easier this way.

[] 6. Move the control cabinet into position next to the main cabinet on the front-right side. Align mounting holes in the main cabinet with those of the control cabinet. Fasten the cabinets together: Use fender washers and the longest of the mounting screws (provided).



[] 7. Games built before May '91: Inside the main cabinet you'll notice a cable harness bundle. Feed the wires through the large hole that connects the main and control cabinets. Feed the wires up through the control cabinet on the front-left side. Notice that the shelves in this corner have a longer notch. This longer notch makes feeding the wires easier.


[] 7A. Games built after April '91: To electronically connect the podium to the main cabinet, locate the 2-16 pin connectors, located near the bottom of the podium at the feed thru hole. Feed it thru, into the main cabinet, and mate it with the connectors, located near the feed thru hole.

WARNING

Before proceeding, be sure the game is unplugged!


[] 8. Install the three Molex® type harness connectors to the CPU Board, if not already connected. Make sure that you install them correctly.

[] 9. Stand the platform on its side, with the step edge guard facing up. Place the step on top. Line up the mounting holes. Attach the step and platform with two fender washers and two short screws (provided).




[] 10. Slide the handrails into the holes on the platform. Secure them with four long carriage bolts and KEP nuts (provided).

[] 11. Place the platform and step assembly by the front of the main cabinet. Find two fender washers and the two longest remaining bolts. To make assembly easier, start from the *inside* of the cabinet front. Now slide the hardware through the holes in the cabinet front. Move the platform into position, leaving a small space between the two units. Look into the space for the platform mounting holes. See that they line up properly. Now start the screws. Push the platform tight up against the main cabinet. Tighten the hardware.



(For simplicity, control cabinet not shown.)

[] 12. Install the playfield to the cabinet using the two allen head screws removed earlier. Make sure to align the playfield properly before tightening the bolts. The playfield should lie at the same level or very slightly below the platform. If not, loosen the cabinet to platform bolts. Now shim the platform slightly, and re-tighten the bolts. Align the playfield and tighten the hardware.



(Note: For simplicity, control cabinet not shown.)

[] 13. Set the display cabinet atop the rear of the main cabinet. Remove the two square drive screws from the graphics panel with the square drive bit (provided). Carefully remove the graphics panel.

[] 14. Fasten the display cabinet to the main cabinet with two fender washers and bolts (provided).

WARNING

Before proceeding, be sure the game is unplugged from the main cabinet!

[] 15. Connect the three-prong power plug into the display cabinet's duplex outlet box (provided). (One plug should already be connected at this location.) Reach into the main cabinet and pull out the Molex connector. Connect the Molex connector to the power supply.

[] 16. Get the display panel. Plug in the display panel connectors at the bottom of the PC board.

[] 17. Slide the display panel into position. Secure the panel with the two square drive screws. Be careful not to pinch wires between the panel and the frame.

[] 18. Install the cover glass and secure it with the six bolts and washers provided.

[] 19. Plug the game in and turn on the power. Listen for unusual sounds. Be sure the game works okay. If the game seems fine, then proceed. Otherwise see the Troubleshooting section or call our service department at 1 (716) 833-0481.

Select game options and pricing as described in this book's section on *Game Adjustments*. After completing game setup and adjustment, close the control panel. Secure it with screws (provided).

Game Testing

[] 1. Be sure a ball is in the game. Test procedures require that a ball is in the game. Check to see that all components are connected or plugged in.

[] 2. Turn on AC power.

[] 3. Enter Test Mode by pushing the TEST button on the main PC board. TEST is inside the control cabinet.

[] 4. Push the HOLE SELECT button.

- Playfield actuators should move up and down in sequence.
- One by one, all seven-segment displays should light. The hole display lights first.
- Watch the actuators. All five should go up and down in sequence at least five times.
- Watch the segments on the displays. Only one segment should light at a time. This segment test helps you check for short circuits between segments.
- Check the playfield. It should vibrate when the center actuator moves to the upper position.
- Check for periodic ball ejection. (*For this mode to work correctly, the ball must be in the game!*) The ball doesn't eject, or the machine ejects the ball off the platform: See "Ball Ejects Too Strongly or Too Weakly," in the *Troubleshooting* section.
- Push TEST and watch the large display. The game leaves Test Mode. All segments and bulbs should light, indicating normal game operation.

[] 5. Push TEST. The game enters Test Mode.

[] 6. Next, we'll examine factory settings. Push GAME SELECT. A ".1" appears at the top of the large display. Simultaneously a "4" appears at the bottom of the display. Advance to the next number by pressing GAME SELECT. Here's the sequence of "." numbers...

.1 and 4

.2 and 1

.3 and 4

.4 and a variable: *Variable should match credits shown on the console display.*

.5 and 1

.6 and 1

.7 and 1

.8 and 0

.9 and 1

These are the factory settings. These numbers may differ from settings on your machine. If so, you may adjust your machine to match the above numbers. (Or you can adjust game performance to your location by altering these numbers. See the *Game Pricing* and *Ticket Dispenser* sections that follow.)

[] 7. Exit Test Mode by pressing TEST.

[] 8. Check to see that there's a battery in the main PC board. Now press both coin switches, or run coins through the mechanisms. Watch the credits display. With the game set for \$1 per credit, inserting four coins should buy one credit. Every additional four coins should purchase four more credits.

[] 9. Adjust the machine's sound level.

[] 10. *Machines with bill validators only:* Insert a \$5 bill in the bill validator. Watch the credits display. With the game set for \$1 per credit, every \$5 should buy five credits.

[] 11. Turn AC power off and on again. Credits should remain in memory. If the game tests okay, continue.

Now you'll want to try some different games to make sure the machine operates correctly. You can choose among three game types...

GAME 1: TOTAL STROKES

In this game, players take turns hitting the ball. They try to get the lowest score, based on the following rules...

- 1 point for sinking a hole in 1
- 2 points for leaving the ball on the green
- 3 points for hitting the ball off the green

If the ball returns to the player, the game invokes a one-stroke penalty. After each player takes his turn, the ball automatically ejects a ball for the next player. If the ball falls back in the hole, the game automatically re-ejects it. After players complete their turns on one hole, the playfield changes shape for the next hole. Players may choose to play nine or eighteen holes. The game ends after players have completed all holes.

GAME 2: HOLE-IN-ONE

This game resembles Game 1: Total Strokes. However in Game 2, players only receive a point for a hole-in-one. The object is to attain the highest score.

GAME 3: PICK-A-PUTT

This is a practice game. The object of the game is to sink as many balls as possible. Players also use this game to brush up on technique. A player selects a nine or eighteen-hole game. Then he chooses a green to putt on. He may shoot all the balls at the same green. Or he may spread the balls out over different greens.

Playing the Game

To play a game, players begin by inserting money. A player needs one credit for a nine-hole game, or two credits for an eighteen-hole game. (The number of coins per credit is operator selectable.)

CONTROL PANEL

Next, the game computer displays the number of credits available on the control panel's readout. The player then chooses the desired game, number of players and number of holes. When players push buttons, the game computer lights an LED beside the current selection. After players complete their selections, they press the START button and begin playing.

Game Pricing

Standard *PUTTING CHALLENGE* machines have two coin mechanisms in their coin doors. Games with options may include a dollar bill acceptor, ticket dispenser, or both. You may adjust pricing to suit your operation and customers. Here are your options...

- One through eight coins for one credit
- Four coins for one credit (factory setting)
- Freeplay

If you have two coin mechanisms, you can set each differently. First adjust the coins per credit setting for Mechanism 1. Then enter the different settings for Mechanism 2. If you desire Mechanisms 1 and 2 to have the same settings, set Mechanism 1 and do nothing to Mechanism 2. The game's computer will adjust Mechanism 2 identically to Mechanism 1's setting.

You can also set the bill acceptor for various credits...

- One bill for four credits
- One bill for three credits
- One bill for two credits
- One bill for one credit (factory setting)
- One bill for one-half credit

WHAT ARE CREDITS?

The game computer has its own standard currency known as credits. Your pricing adjustment sets the "exchange rate" or how many coins buy a credit. At the factory setting (default), one credit is four coins. That is, four coins buy one player a nine-hole game of golf. Eight coins would then buy him an eighteen-hole game of golf.

Adjusting Game Pricing

CAUTION

Pushing the TEST button cancels any game in progress.

To enter Game Pricing Mode, first open the control panel. On the CPU Board is a test button. Be sure you've turned on the game. Press the TEST button. A decimal point at the top of the display panel lights, indicating the Test Mode. Press the GAME SELECT button. The display changes to a "1." This indicates that you're in the Game Pricing Mode, and ready to begin.

The following describes what the numbers mean, and how to adjust them.

1. NUMBER OF COIN #1's PER CREDIT

This figure represents coins per credit for the left coin chute in a two-chute door. Or, this figure can represent coins per credit in a one-chute door. Look for a number in the bottom display. This number shows how many coins players need to get one credit. To change this amount, repeatedly press **PLAYER SELECT** until the desired number of coins appears. Pressing "0" causes the machine to enter its Freeplay Mode. When finished, press **GAME SELECT** to advance to the next option. (To return the game to normal operation, press **TEST** anytime.)

0 =
Free
play

2. NUMBER OF COIN #2's PER CREDIT

With a two-chute coin door, this figure represents the right coin chute's credit setting. (The figure *isn't* used with single-chute doors.) Notice the number at the bottom of the display. This number is a multiplier for the Coin #1 setting. Example: You set Coin Chute #1 to four coins. The bottom display number (credits) should be a "1." Here's why: $4 \times 1 = 4$ coins per credit for Chute #2. Normally, you'll set Pricing Adjustment 2 to "1." However, you may use other settings for foreign or special purposes. *If you have a special use, contact our service department for the correct settings.* To change Pricing Adjustment 2, repeatedly press **PLAYER SELECT** until the desired number appears. When finished with Adjustment 2, press **GAME SELECT** to advance to the next option. (To return the game to normal operation, press **TEST** anytime.)

0

3. NUMBER OF CREDITS PER BILL

This figure represents the number of credits per one-unit (dollar) bill. The number at the bottom of the display panel shows the number of credits per unit. To change this, press **PLAYER SELECT**. Pressing "0" shuts the accepting mode off. When finished, press **GAME SELECT**. (Some machines have bill acceptors that accept more than one unit, that is, dollar bills. Games with these acceptors multiply credits by units. Example: One dollar buys one credit; five dollars, five credits.)

0

4. CURRENT CREDITS

This figure represents the number of credits currently in memory. Use this feature to remove or add credits to this number. You can also use this feature to provide a one-time freeplay. With Feature 4, you can add credits without changing the coins per credit function. Here's how: The game computer displays credits at the bottom of the control panel. Adjust them by pressing **PLAYER SELECT**. When finished, proceed to the next feature by pressing **GAME SELECT**.

Adjusting the Ticket Dispenser

5. GAME #1: 1-PUTT TICKETS

This feature adjusts the number of tickets dispensed per hole-in-one for Game 1 (Total Strokes). The game computer posts the number of tickets on the bottom display. To adjust Feature 5, press PLAYER SELECT. Pressing "0" disables the dispensing function. When finished, proceed to the next feature by pressing GAME SELECT.

6. GAME #1: TICKETS FOR BALLS ON THE GREEN

This feature adjusts the number of tickets dispensed for balls remaining on the green in Game 1 (Total Strokes). The game computer posts the number of tickets on the bottom display. To adjust Feature 7, press PLAYER SELECT. Pressing "0" disables the dispensing function. When finished, proceed to the next feature by pressing GAME SELECT.

7. GAME #2: 1-PUTT TICKETS

This feature adjusts the number of tickets dispensed per hole-in-one for Game 2 (Hole-in-One). The game computer posts the number of tickets on the bottom display. To adjust Feature 6, press PLAYER SELECT. Pressing "0" disables the dispensing function. When finished, proceed to the next feature by pressing GAME SELECT.

8. GAME #3: PICK-A-PUTT TICKETS

This feature adjusts the number of tickets dispensed per hole-in-one for Game 3 (Pick-A-Putt). The game computer posts the number of tickets on the bottom display. To adjust Feature 7, press PLAYER SELECT. Pressing "0" disables the dispensing function. When finished, proceed to the next feature by pressing GAME SELECT.

9. GAME #1: 2-PUTT TICKETS

Use this option to dispense tickets to players who normally can't get tickets during the game. Feature 9 can be helpful if your customers are children or newcomers to the game. Also, some locations want the machine to dispense tickets regardless of score. The game computer posts the number of tickets on the bottom display. To adjust Feature 9, press PLAYER SELECT. Pressing "0" disables the dispensing function. When finished, proceed to the next feature by pressing GAME SELECT. To exit Ticket Mode and return to Play Mode, press TEST. (You'll find the TEST button on the CPU Board.)

Accounting Mode

Because *PUTTING CHALLENGE* is computer controlled, it can provide a history of game activity. We call this characteristic the "Accounting Mode." Accounting Mode supplies useful information about gameplay on your machine. For instance...

- How many games have people played at this machine?
- How many games did people play here in the last week?
- How many people play at once?
- How many one, two, three or four-player games did people play?
- What types of game were people playing? (How many Game 1: Total Strokes, Game 2: Hole-in-One and Game 3: Pick-A-Putt did they play?)

CAUTION

Pushing the TEST button cancels any game in progress.

Using Accounting Mode

Be sure your machine is on. Open the control panel and press TEST. (You'll find the TEST button on the CPU Board.)

When you press TEST, a decimal point appears on the top display. Push PLAYER SELECT. Now a "1.1" appears on the top display. This figure indicates the game computer's entry into Accounting Mode.

1.0 TOTAL CREDITS SINCE CREATION

This figure represents the total number of credits registered on the game. The game computer began counting this number when you last replaced the CPU Board battery. (*You may be still using the original battery. In that case, this number represents total credits since the game began operation.*) After viewing this number, proceed to the next feature by pressing GAME SELECT. (*To exit Accounting Mode, press TEST.*)

1.1 TOTAL CREDITS SINCE LAST CLEAR

This figure represents the total credits since you last cleared credits from memory. Use Feature 1.2 as a weekly, monthly, or periodic resettable device. Feature 1.2 makes finding out how the game is earning and verifying cashbox coin count easier. You can reset this feature by pressing PLAYER SELECT. Proceed to the next feature by pressing GAME SELECT.

1.2 NUMBER OF GAME #1 PLAYS

This figure represents the number of "Total strokes" games played since the last time you reset Feature 1.3. You can reset this feature by pressing PLAYER SELECT. Proceed to the next feature by pressing GAME SELECT.

1.3 NUMBER OF GAME #2 PLAYS

This figure represents the amount of "Hole-in-One" games played since the last time you reset Feature 1.4. You can reset this feature by pressing PLAYER SELECT. Proceed to the next feature by pressing GAME SELECT.

1.4 NUMBER OF GAME #3 PLAYS

This figure represents the number of "Pick-A-Putt" games played since the last time you reset Feature 1.5. You can reset this feature by pressing PLAYER SELECT. Proceed to the next feature by pressing GAME SELECT.

1.5 NUMBER OF 1-PLAYER PLAYS

This figure represents the number of one-player games played since the last time you reset this feature. You can reset this feature by pressing PLAYER SELECT. Proceed to the next feature by pressing GAME SELECT.

1.6 NUMBER OF 2-PLAYER PLAYS

This figure represents the number of two-player games played since the last time you reset this feature. You can reset this feature by pressing PLAYER SELECT. Proceed to the next feature by pressing GAME SELECT.

1.7 NUMBER OF 3-PLAYER PLAYS

This figure represents the number of three-player games played since the last time you reset this feature. You can reset this feature by pressing PLAYER SELECT. Proceed to the next feature by pressing GAME SELECT.

1.8 NUMBER OF 4-PLAYER PLAYS

This figure represents the number of four-player games played since the last time you reset this feature. You can reset this feature by pressing PLAYER SELECT. Proceed to the next feature by pressing GAME SELECT.

To review Accounting Mode, repeatedly press GAME SELECT. To exit Accounting Mode, press TEST.

Maintenance Tips

Your collections depend on how well you maintain your game. It's a fact! Well-maintained games earn more and earn longer!

Fortunately, *PUTTING CHALLENGE* is easy to care for. Maintaining your game is pretty much a matter of common sense. Here are a few pointers to get you started...

- **CLEAN THE GLASS.** Keep the cover glass clean by wiping with a glass cleaner. Follow that with a furniture polish (we recommend Pledge™). You could also use a special plastic polish available from us, ICE Inc. The polish is important. It protects the plastic against haze and aging. Machine buffing can remove scratches that aren't too deep: Be sure to use a scratch remover available from ICE.
- **VACUUM THE PLAYFIELD,** platform and steps regularly. Vacuuming keeps dust from fouling the ball return. Vacuuming also keeps your game looking clean and new...and attractive to players!
- **REPLACE WORN CARPETING.** Use only carpet supplied by ICE! Other carpet materials work poorly with the game. (Common carpet types may cause the ball to stick on the playfield.) Follow instructions provided in the replacement carpet kit.
- **INSPECT THE HANDRAILS.** Regularly check the handrails. If necessary, tighten them.
- **REPLACE MEMORY BATTERY.** Every five years, replace the CPU Board battery. Use only the same type and size battery.
- **LUBRICATE ACTUATORS.** Occasionally lubricate the actuator pivot points with a good grade machine oil. Also lightly grease the rub pads on the bottom of the playfield.

•**MAINTAIN GAME LIGHTING.** Light bulbs illuminate the playfield, display cabinet, display panel and buttons. Some of these bulbs indicate game functions. Your game's operation and attractiveness depend on these bulbs. After all, without indicator lamps, no one can play the game! The game uses four types of light bulbs...

Bulb Location	Bulb Type
• Console Buttons and Coin Chutes	#194, 12-volt bulbs
• Display Cabinet	#F20T12/CW, 120-volt bulbs
• Display PC Board	#161, 12-volt bulbs
• Main Cabinet Lighting	#F40/CW, rapid start 120-volt bulbs

Troubleshooting

This section describes problems along with their probable solutions. Solutions appear in this order: Most likely *first*, least likely *last*. We also describe assembly or replacement.

CAUTION

When working on the machine, be extremely careful with the electronics. Misconnections *or even meter probes* can easily damage electronic parts. Don't attempt any repair until you're sure of the correct solution. If you have any questions, call our service department before proceeding!

•SYMPTOM: BALL WON'T EJECT

Possible Problem	Solution
Bad solenoid	Replace solenoid
Bad or dirty ball sensor	Clean or replace sensor
Dirt in tray or ball tube	Clean ball tray and tube
Bad solenoid driver	Replace driver
Bad CPU Board	Repair CPU Board
Bad connector or harness	Repair harness or connector
Loose solenoid	Tighten screws; Use <i>thread-locking compound</i>
Bad power supply	Repair power supply
Ball eject adjusted too low	Adjust to proper setting

ACCESS TO THE BALL-FEED SOLENOID

- () 1. Remove the screws and washers that retain the cover glass.
- () 2. Remove the glass.
- () 3. Remove the two long screws that retain the playfield. You'll find these screws at the front of the playfield.
- () 4. Lift the back of the playfield. Disconnect the four-pin connector for the shaker motor and hole microswitch.
- () 5. Carefully remove the playfield.
- () 6. Loosen the band clamp on the ball-return pipe. Slide the return pipe out of the tee fitting.
- () 7. Disconnect the three-pin connector on the optical PC Board. Remove the two fast-on connectors from the solenoid coil.
- () 8. Lift the solenoid assembly up. You now have access to the solenoid and optical detector.
- () 9. To reassemble the game, reverse this procedure.

EJECTOR ASSEMBLY MAINTENANCE

When a ball falls into the ejector cup, the ball must trigger the optical sensor. Periodically clean the sensor assembly with a clean, damp cloth. Pay particular attention to the optical LED's. Make sure that they're dirt-free and unobstructed!

To clean the tray and the tube, first remove the tray. Then clean the outside of the game. There may be debris in the tube. Clean it out! Wrap a rag around a coat hanger and push it through the pipe. (If you don't have a coat hanger, then any stiff wire will do fine.) You can also blow debris out of the tube if you have a shop vac. Set the hose on exhaust, insert other end of the hose into the ejector pipe. This will blow any dirt, etc. into the ball return tray, where it can be easily vacuumed out.

•**SYMPTOM: ACTUATORS DON'T WORK**

Possible Problem	Solution
Worn motor brushes	Replace motor
Worn gearbox or bad gear teeth	Replace gearbox
Loose hardware	Tighten hardware: Use <i>thread-locking compound</i>
Bad Sensor Board	Replace board
Bad CPU Board	Repair board
Bad harness	Repair harness
No lubrication; bad pivot points	Replace parts and be sure to lubricate them!

CAUTION

REPLACING ACTUATORS. Make sure that you replace actuators in the correct positions! Otherwise, you might damage the playfield. Notice that the actuators have two different height settings. Return actuators with a *three-inch rise* to the front of the machine. Those with a *four-inch rise* go in the middle and rear. The front of the game is the end closest to the player.

NOTICE

ACTUATOR HEIGHT CONVERSIONS. ICE, Inc. can easily assist you in converting a lifter for either height that your machine uses. For more information, call our service department. See *Questions or Comments*.

ACCESS TO PLAYFIELD ACTUATORS

- () 1. Remove the screws and washers that retain the cover glass.
- () 2. Remove the glass.
- () 3. Remove the two long screws that retain the playfield. You'll find these screws at the front of the playfield.
- () 4. Lift the back of the playfield. Disconnect the four-pin connector for the shaker motor and hole microswitch.
- () 5. Carefully remove the playfield. Removing the playfield exposes the front playfield actuators for service.
- () 6. To gain access to rear actuators, remove the tray retaining screw and tray.
- () 7. To reassemble the game, reverse this procedure.

•**SYMPTOM: GAME DOESN'T RECOGNIZE BALL IN PLAY**

Possible Problem	Solution
Misaligned optical detector	Check alignment. Verify it by lit LED on the receiver.*
Bad optical detector*	Replace detector
Bad CPU Board	Repair board

*Call our service department for additional information.

Check detector covers for obstructions. Blocked detectors may not work correctly. Also, be sure that the playfield is firmly attached. Check playfield alignment, too: Can detectors see through the cover openings?

•**SYMPTOM: BALL EJECTS TOO STRONGLY OR TOO WEAKLY**

You can easily adjust ball-ejection power. On earlier machines, the adjustment is on a rheostat near the ejector unit. On later models, the rheostat is on the power supply. In both cases, reduce ejection power by turning the rheostat counterclockwise. Turning clockwise increases power. The ball should eject between six and eighteen inches from the hole.

•**SYMPTOM: GAME DOESN'T HOLD CREDITS OR RETAIN MONEY AND TICKET SETTINGS**

The battery on the CPU Board is probably worn out. Replace it with the same size and type, and reset the machine. Try to replace the battery *before* it's worn out. In that case, the game retains memory long enough for the battery to be changed. We recommend that you replace the battery at least every five years.

Questions or Comments

If you have questions or comments, please call our service department. Phone 1 (800) 342-3433 or 1 (716) 833-0481.

NOTES . . .

PUTTING CHALLENGE SPARE PARTS LISTINGS



PC 10004X	ACTUATOR ASSEMBLY
PC 10004	ACTUATOR MOUNTING BRACKET
PC 10005X	ACTUATOR PUSH ROD
PC 10006	ACTUATOR SENSOR DISC
PC 10007	ACTUATOR PISTON
PC 10008	ACTUATOR PISTON BEARING
PC 10009A	ACTUATOR SWING ARM ASSEMBLY
PC 10010	STEP GUARD EDGING
PC 10015X	SOLENOID BALL CUP
PC 20201	ACTUATOR GEARMOTOR
PC 20203	48" FLUORESCENT LIGHT BALLAST (OLD STYLE)
PC 20203C	48" FLUORESCENT LIGHT BALLAST (NEW STYLE)
PC 20205	BULB LOCKS
PC 20206	BULB SOCKET, REGULAR
PC 20206A	BULB SOCKET, INTERRUPT
PC 20218	GAME SELECT BUTTON
PC 20219	PLAYER SELECT BUTTON
PC 20220	HOLE SELECT BUTTON
PC 20221	START SELECT BUTTON
PC 20222	BALL CUP MICRO SWITCH
PC 20222A	BALL CUP MICRO SWITCH BRACKET
PC 20224	GAME COUNTER
PC 20225	EJECTOR SOLENOID WITH PLUNGER
PC 20225A	EJECTOR SOLENOID PLUNGER ONLY
PC 2007	SPEAKER
PC 20228	VIBRATOR MOTOR
PC 20348X	EMITTER/RECEIVER CABLE
PC 20349X	CARPET CABLE
PC 20394X	BALL EJECT ASSEMBLY SENIOR (WITH SOL.)
PC 20394XA	BALL EJECT ASSEMBLY JUNIOR (W/O SOL.)
PC 20400	74LS04 I.C.
PC 20401	5821A I.C.
PC 20402	4093 I.C.
PC 20403	L298N
PC 20404	74HC14N I.C.
PC 20405	LM358 SOUND AMP I.C.
PC 20406	27512 E-PROM GOLF SOUND
PC 20407	BATTERY 3 VOLT CR2025
PC 20408	MAN 6610 7 SEGMENT DISPLAY
PC 20409	MAN 6910 7 SEGMENT DISPLAY
PC 20410	5K VOLUME POTENTIOMETER
PC 20411	.250 MALE FAST-ON
PC 20415	68705 SOUND CHIP 1.0
PC 20416	68705 LOGIC CHIP 5.3
PC 20421	BRIDGE RECTIFIER (BR2) VJ048M
PC 20422	BRIDGE RECTIFIER RB151-ND
PC 20423	IRF 540
PC 20424	F1 FUSE - 10 AMP
PC 20425	F2 FUSE - 10 AMP
PC 20426	10,000 MFD, 25 VOLT ELECT. CAPACITOR
PC 20427	10,000 MFD, 50 VOLT ELECT. CAPACITOR
PC 20428	POWER SUPPLY TRANS. 110 VOLT 4-42-8400
PC 20429	RED L.E.D. (INDIVIDUAL FOR DISP.P.C.B.)
PC 20430	100 OHM WIRE WOUND RESISTOR
PC 20431	RESISTOR NETWORK, 1K 760-3-R1K
PC 20432	4 MHZ QUARTZ CRYSTAL
PC 20433	OPTOISOLATOR OPB742
PC 20434	TIP 120 SWITCHING TRANSISTOR
PC 20435	VOLTAGE REGULATOR
PC 20436	RESISTOR NETWORK 560 OHM
PC 30302X	GOLF CLUB ASSEMBLY
PC 30302	GOLF CLUB WITH MOUNTING HOLE
PC 30303X	PLAYFIELD COVERGLASS ASSEMBLY
PC 30304X	DISPLAY PANEL ASSEMBLY
PC 30306X	PLAYFIELD ASSEMBLY SENIOR (ALL COMP.)

PC 30306XA	PLAYFIELD ASSEMBLY JUNIOR (REPLACEMENT)
PC 30308	ACTUATOR WEAR PADS
PC 30309	BALL CUP
PC 30310	BALL RETURN TRAY
PC 30318	I.R. EMITTER COVER
PC 30319	I.R. RECEIVER COVER
PC 30321	48" FLUORESCENT LIGHT COVER
PC 30322XA	STEP GRASS ASSEMBLY (W/ADHESIVE)
PC 30323XA	PLATFORM GRASS ASSEMBLY (W/ADHESIVE)
PC 30328	Z CHANNEL (LIGHT COVER SUPPORT)
PC 50502	CASH BOX
PC 50507	SPEAKER GRILLE
PC 50508	3/16 VINYL COATED CABLE, 5 FEET (CLUB)
PC 60601	COVER GLASS BOLT, 1/4-20 X 1 1/4
PC 60601A	ALLEN WRENCH, COVER GLASS BOLT
PC 60602	1/4-20 X 1 1/4 SOCKET HEAD, BOLT
PC 60603	10-24 X 1/2 SHCS
PC 60604	1/4-20 NYLOCK NUT
PC 6006	1/4 X 3/8, 10-24 THREAD SHOULDER BOLT
PC 60606	8-32 X 3/8 ALLEN HEAD SET SCREW
PC SK613	#8 STAR WASHER
PC 3008	1/4 X 1/2 X .060 PLASTIC WASHER
PC 6004	8-32 X 1/2 MACHINE SCREW
PC 655	#8 X 3/4 SQUARE DRIVE SCREW
PC 60615A	#8 SQUARE DRIVE BIT
PC 60617	1/4 -20 X 4 PHILLIPS HEAD BOLT
PC 60622	1/4-20 X 1 CAP SCREW, ALLEN HEAD
PC 3036	COVER GLASS BOLT WASHER
PC 60625	3" HOSE CLAMP
PC 60626	6-32 X 3/4 PEM STUD
PC 6005	8-32 X 1/4 PHILLIPS HEAD MACHINE SCREW
PC 60631	CABINET INSERT, 1/4-20
PC 60632	PLASTIC FEET
PC 60633	O RING
PC 60636	1/4-20 X 3 ALLEN HEAD BOLT (PLAYFIELD)
PC 60637	5/16-18 X 3 1/2 CARRIAGE BOLT (RAILING)
PC 60638	5/16-18 KEP NUT (RAILING)
PC 60641	6-32 X 5/8 HEX HEAD SPACER
PC 60642	6-32 X 3/8 HEX HEAD SPACER
PC 60647	8-32 NUT
PC 60648	1/8" SPACER TUBE
PC 60650	1/4" CAST EYE BOLT (GOLF CLUB)
PC 60653	FERRULES, CABLE CLAMP
PC 60656	EYE BOLT PUSH NUT (GOLF CLUB)
PC 70701	GOLF BALL DECAL
PC 70702	"PUTTING" DECAL
PC 70702A	"CHALLENGE" DECAL
PC 70706	"HAZARD AREA" DECAL
PC 70707	"AUTOMATIC BALL RETURN" DECAL
PC 70710	SERVICE MANUAL


ELECTRONIC PARTS LISTINGS

PC 20229	ACTUATOR P.C. BOARD
PC 20230	I.R. RECEIVER P.C. BOARD
PC 20231	I.R. EMITTER P.C. BOARD
PC 20232	POWER SUPPLY P.C. BOARD
PC 20233	HOLE DISPLAY
PC 20234	MAIN P.C. BOARD
PC 20235	DISPLAY P.C. BOARD
PC 20236	CONSOLE P.C. BOARD
PC 20394	BALL EJECT P.C. BOARD


(ALL OTHER ELECTRONIC PARTS LISTED IN MAIN LIST IN 20000 SERIES.)





ASSY




* ALL COMPONENTS SHOWN.
 ** FOR PLAYFIELD REPLACEMENT.






zone	rev	description	date	approved



ICE INC.	
COIN OPERATED GOLF GAME	
CONSOLE PANEL	
SCHEMATIC	
sizeCode	id drawing no.
B	
no.	
scale	Sheet 3 of 3




zone	rev	description	date	approved
	1			



ICE Inc.	
OPTICAL BALL SENSOR	prepared GHD 11-90
OPTO RECEIVER CIRCUIT	checked
	engineer
size	code id
A	draughts no.
scale	NA
sheet 2 of 2	



1 2 3 4 5 6 7 8

zone	rev	description	date	approved




ICE																						
Bell Return Opto Board																						
<table border="1"> <tr><td>approved</td><td>10-90</td><td>GH0</td></tr> <tr><td>checked</td><td></td><td></td></tr> <tr><td>engineer</td><td></td><td></td></tr> </table>	approved	10-90	GH0	checked			engineer			<table border="1"> <tr><td>size</td><td>code</td><td>id</td><td>drawing no.</td></tr> <tr><td>A</td><td></td><td></td><td></td></tr> <tr><td>scale</td><td></td><td></td><td></td></tr> </table>	size	code	id	drawing no.	A				scale			
approved	10-90	GH0																				
checked																						
engineer																						
size	code	id	drawing no.																			
A																						
scale																						
Sheet 1 of 1																						

revisions		date	approved
zone	tr		



ICE Inc.	
COIN OPERATED GOLF GAME DISPLAY PANEL SCHEMATIC	
prepared 12/90 GMD	size code id drawing no.
checked	C no.
engineer	scale
sheet 2 of 3	



NOTE:
ALL RESISTORS ARE
1/4W 5% C.F. UNLESS
OTHERWISE NOTED.


UNLESS OTHERWISE SPECIFIED
DIMENSIONS ARE IN INCHES
TOLERANCES ARE:
FRACTIONS DECIMALS ANGLES
± .XX ± .XXX ±

APPROVAL	DATE
DESIGNED BY A.J. PALCZEMSKI	1-02-91
CHECKED BY A.S. PEARCE	1-03-91
DRAWN BY DORC	
DATE FOR WORK	

<p>polyfusion ELECTRONICS, INC. LANCASTER, NEW YORK 14088</p>	
<p>PUTTING CHALLENGE POWER SUPPLY SCHEMATIC</p>	
SIZE B	PART NO. 60-PCPS
SCALE 1"	SHEET 1 OF 1
DATE 910102-1	REV. E

ST 0AA 99108 U13


revisions		date	approved
zone	ltr		



NOTE: All Resistors are 5% 1/4 watt unless otherwise noted

REV 3		ICE Inc.	
prepared	12/90	COIN OPERATED GOLF GAME	
checked		MAIN LOGIC SCHEMATIC	
engineer		size	code id
		no.	drawing no.
		scale	sheet 1 of 3

zone	1	2	3	4	5	6	7	8	9	10
revision										
description										
date approved										




* DENOTES FACTORY OPTION ITEMS

ICE INC.	
GOLF HOLE DISPLAY	
prepared 12/21/80	size/code id/drawing no.
checked	A
inspected	scale
sheet 1 of 1	

1 blk - 8 blk
 6 blue - 2 blue
 7 pop - 6 purple
 9 white - 6 green
 11 white - 1 red
 12 black - 7 brown
 14 red - 5 white

16 Green - +5Vc
 13 - Brown - DGND

1- Black
 2- Blue
 3- -
 4- Green
 5- white
 6- purple
 7- Brown
 8- Black
 9- white



REVISIONS				
LTR.	DESCRIPTION	BY	DATE	APP.

P4
 1 - black
 2 - blue
 3 - blue
 4 - orange
 5 - green
 6 - red

Cup switch
 16 - 12v (red)
 13 - Ground (blk)

ITEM	DESCRIPTION	NO. REQ'D	PART NO.	MATERIAL

LIST OF MATERIALS		BY DATE		* I.C.E.	

14 CLK -> red reads 12v
 16 GND -> reads 5v

Ball switch @ eject solenoid

100 100

101 - 80k
102 - 20k
103 - 10k
104 - 5k
105 - 1k
106 - 500
107 - 200

108 - 100
109 - 50

1 - Black	1 - Black
2 - Blue	2 - Blue
3 -	3 -
4 - Purple	4 - Purple
5 - Green	5 - Green
6 - White	6 - White
7 - Purple	7 - Purple
8 - Green	8 - Green
9 - Black	9 - Black
10 -	10 -

PI01

- 1 12v - Red ✓
- 2 data 2d - Blue?
- 3 N/A -
- 4 5v - Green ✓
- 5 CLK - white ✓
- 6 Latch - purple?
- 7 Dgnd - Brown
- 8 Sgnd - Black



From PI

- 1-Sgnd - blk
- 6-data - blue
- 7 latch - purple
- 11-12v - white
- 12-Dgnd - blk
- 14-CLK - red
- 9-5v - white



Have from PI

- 1-blk - Sgnd - 1 (PI01)
- 6 - blue - data - 6 (PI01)
- 7 - purple - latch - 7 (PI01)
- 11 - white - 3Z
- 13 - brown - 7 8 25 - 9 8 5 (PI01)
- 14 - red - 12v
- 16 - green - 5v - 4 sv (PI01)

1586-166

PI

- 1 Sgnd - blk
- 2 -
- 3-12v blk
- 4 gnd baby blue
- 5 gnd blk
- 6 25 blue
- 7 1GZ purple
- 8-5v orange
- 9-5v white/gray
- 10-5v green/gray
- 11-3Z white/gray
- 12-gnd blk
- 13-gnd brown
- 14-12v red
- 15-12v pink
- 16-5v green

PI

- 1 Sgnl
- 2 N/A
- 3 12v
- 4 dgnl
- 5 dgnl
- 6 - data
- 7 - Latch
- 8 - eye
- 9 5v
- 10 12v
- 11 12v
- 12 dgnl
- 13 dgnl
- 14 - CLK
- 15 bell switch
- 16 cup switch

6 } come from U3 (chip) 6 = 25 P80
7 } 7 = 26 P81 > LS04 - 611
14 } 14 = 27 P82