

ATOMIC POINT







OPERATOR'S MANUAL

CHARACTERISTIC ATOMIC POINT


1. OUTSTANDING CONCEPTION.
2. PLAYER CAN SELECT A FAVORITE STAGE PATTERN AMONG 100 DIFFERENT STAGES.
3. OPTIONS AVAILABLE TO UTILIZE IN GAME.
4. POWER BLOCKS CONTAIN IN STAGE PATTERNS.
5. GAME SELECTABLE BETWEEN NORMAL TETRIS AND ATOMIC POINT.
6. 2 PLAYERS AVAILABLE AT THE SAME TIME.

OPTION INSTRUCTION ■

1. POWER BLOCKS

FEATURE	NAME	DESCRIPTION
	TICK	Increasing and Moving
	TOCK	Erasing and Moving
	SPARK	Shape desired block by contacting to spark line
	PONG	Erase blocks vertically and drop down
	BOMB	Bomb adjacent blocks
	AMOEBEA	Snap dropping blocks

CONTROL PANEL LAYOUT ■



4 WAY JOY STICK



BUTTON FOR ROTATING BLOCK




OPTION BUTTON

DIP SW POSITION ■


VOLUME

DIP SW 2

DIP SW 1




2. OPTION BLOCK



:When player get a chance of optional block, press option button

and can select a option desired from 4 different options

(SELECT OPTION)



NAME	DESCRIPTION
BLOCK	Select shape of blocks
PONG	Erase blocks vertically and drop down
BOMB	Bomb adjacent blocks
TURTLES	Speed down

PIN ASSIGNMENT ■

SOLDER SIDE			COMPONENT SIDE
GND	A	1	GND
GND	B	2	GND
+5V	C	3	+5V
+5V	D	4	+5V
	E	5	
+12V	F	6	+12V
	G	7	
	H	8	
Coin Counter 2	I	9	Coin Counter 1
SPEAKER (-)	J	10	SPEAKER (+)
	K	11	
GREEN	L	12	RED
SYNC	M	13	BLUE
	N	14	Video GND
	O	15	
COIN 2	P	16	COIN 1
2P START	Q	17	1P START
2P UP	R	18	1P UP
2P DOWN	S	19	1P DOWN
2P LEFT	T	20	1P LEFT
2P RIGHT	U	21	1P RIGHT
2P ROTATE	V	22	1P ROTATE
2P OPTION	W	23	1P OPTION
	X	24	
	Y	25	
	Z	26	
GND	a	27	GND
GND	b	28	GND

DIP SW 1

Coin/Credit option switch setting

ITEM	DESCRIPTION	1	2	3	4	5	6	7	8
COIN	1 coin 1 credit	off	off	off	off	off	off		
	1 coin 2 credit	off	off	on	off	off	on		
	1 coin 3 credit	off	on	off	off	on	off		
	1 coin 4 credit	off	on	on	off	on	on		
	1 coin 5 credit	on	off	off	on	off	off		
	2 coin 1 credit	on	off	on	on	off	on		
	3 coin 1 credit	on	on	off	on	on	off		
	4 coin 1 credit	on	on	on	on	on	on		
NUMBER OF PLAYER	1 player							off	off
	2 player							on	off
	3 player							off	on
	5 player							on	on
					COIN A		COIN B		

DIP SW 2 ■

Option switch setting

ITEM	DESCRIPTION	1	2	3	4	5	6	7	8
GAME DIFFICULTY	NORMAL	off	off						
	EASY	off	on						
	HARD	on	off						
	HARDEST	on	on						
SCREEN FLIP	NORMAL				off				
	REVERSE				on				
MUSIC in DEMO	YES					off			
	NO					on			
CONTINUE GAME	YES						off		
	NO						on		
GAME MODE	normal Tetris							off	
	Atomic Point							on	
TEST MODE	YES								off
	NO								on



Philko Corporation

ADD.: #193, NAKWON-DONG, JONGRO-GU,
 SEOUL, KOREA
 TELEX: PHILKO K29617
 FACSIMILE: (02) 274-2846
 TEL.: (02) 741-0101, 744-1128(DIRECT)