

CLASS OF 81 MS PAC-MAN / GALAGE

PINOUT

* See Notes

	Solder Side				Component Side
	Ground	A	1		Ground
	Ground	B	2		Ground
	+5v	C	3		+5v
	+5v	D	4		+5v
	N/A	E	5		N/A
	12V DC	F	6		12V DC
	N/A KEYWAY	H	7		N/A KEYWAY
	N/A	J	8		Coin Counter
	N/A	K	9		N/A
	Speaker -	L	10		Speaker +
	N/A	M	11		N/A
	GREEN	N	12		RED
	C. SYNC	P	13		BLUE
	N/A *see notes	R	14		VIDEO GROUND
	N/A	S	15		TEST SW
	COIN 2	T	16		COIN 1
Ms Pacman	P2 START	U	17		P1 START
	P2 UP **	V	18		P1 UP
	P2 DOWN **	W	19		P1 DOWN
	P2 LEFT **	X	20		P1 LEFT
	P2 right **	Y	21		P1 right
	** Galage p2 fire	Z	22		Galage P1 fire
Galage	P2 START	a	23		P1 START
	N/A	b	24		N/A
	N/A	c	25		N/A
	N/A	d	26		N/A
	Ground	e	27		Ground
	Ground	f	28		Ground

*R is service switch location on solder side of the PCB there is no connection for this switch on this PCB. Pad is missing

** For Cocktail use only