

CLASS OF 81 MS PAC-MAN / GALAGE

PINOUT

* See Notes

	Solder Side				Component Side	
	Ground	A	1		Ground	
	Ground	B	2		Ground	
	+5v	C	3		+5v	
	+5v	D	4		+5v	
	N/A	E	5		N/A	
	12V DC	F	6		12V DC	
	N/A KEYWAY	H	7		N/A KEYWAY	
	Video Green	J	8		Video Ground	
	N/A	K	9		N/A	
	Speaker -	L	10		Speaker +	
	N/A	M	11		N/A	
	GREEN	N	12		RED	
	C. SYNC	P	13		BLUE	
	N/A *see notes	R	14		VIDEO GROUND	
	N/A	S	15		TEST SW	
	COIN 2	T	16		COIN 1	
Ms Pacman	P2 START	U	17		P1 START	Ms Pacman
	P2 UP **	V	18		P1 UP	
	P2 DOWN **	W	19		P1 DOWN	
	P2 LEFT **	X	20		P1 LEFT	
	P2 right **	Y	21		P1 right	
**	Galage p2 fire	Z	22		Galage P1 fire	
Galage	P2 START	a	23		P1 START	Galage
	N/A	b	24		N/A	
	N/A	c	25		N/A	
	N/A	d	26		N/A	
	Ground	e	27		Ground	
	Ground	f	28		Ground	

*R is service switch location on solder side of the PCB there is no connection for this switch on this PCB. Pad is missing

** For Cocktail use only