

Gang - Wars

Gang Wars

ITEM	CONTENTS	1	2	3	4	5	6
STOP VIDEO DISPLAY	NORMAL	OFF					
	STOP	ON					
FLIP FLOP DISPLAY	NORMAL		OFF				
	REVERSE		ON				
COIN 1	1 COIN 1 CREDIT			OFF	OFF	OFF	
	1 COIN 2 CREDIT			OFF	OFF	ON	
	1 COIN 3 CREDIT			OFF	ON	OFF	
	1 COIN 4 CREDIT			OFF	ON	ON	
	1 COIN 5 CREDIT			ON	OFF	OFF	
	2 COIN 1 CREDIT			ON	OFF	ON	
	3 COIN 1 CREDIT			ON	ON	OFF	
COIN 2	5 COIN 1 CREDIT			ON	ON	ON	
	1 COIN 1 CREDIT			OFF	OFF	OFF	OFF
	1 COIN 2 CREDIT			OFF	OFF	ON	OFF
	1 COIN 3 CREDIT			OFF	ON	OFF	OFF
	1 COIN 4 CREDIT			OFF	ON	ON	OFF
	1 COIN 5 CREDIT			ON	OFF	OFF	OFF
	2 COIN 1 CREDIT			ON	OFF	ON	OFF
	3 COIN 1 CREDIT			ON	ON	OFF	OFF
	5 COIN 1 CREDIT			ON	ON	ON	OFF
1 COIN 1 CREDIT						ON	
NUMBER OF COIN SHOOTER	2						OFF
	1						ON

DIP SWITCH 2

2 BIT 3 BIT 4 BIT 5 BIT 6 BIT 7 BIT

ITEM	CONTENTS	1	2	3	4	5	6
		OFF					
LIVES	3		OFF				
	4		ON				
TIME COUNT	NORMAL			OFF			
	SLOW			ON			
DIFFICULTY LEVEL	EASY				OFF	ON	
	NORMAL				OFF	OFF	
	DIFFICULT				ON	OFF	
	VERY DIFFICULT				ON	ON	
ATTRACTION SOUND	WITH						OFF
	WITHOUT						ON