

コインスイッチNo.2セット

5	6	7	8	コイン	プレイ
OFF	OFF	OFF	OFF	1	1
ON				1	2
OFF	ON			1	3
ON				1	4
OFF	OFF	ON	OFF	1	5
ON				1	6
OFF	ON			1	7
ON				2	1
OFF	OFF	OFF	ON	2	3
ON				2	5
OFF	ON			3	1
ON				3	2
OFF	OFF	ON	ON	3	4
ON				4	1
OFF	ON			4	3
ON				無効	

コインスイッチ No.2 セット

プレイヤー数

SW	1	2	プレイヤー数
OFF	OFF		2
ON			3
OFF	ON		4
ON			7

テーブル/アップライト 切り換え

SW	3	タイプ
OFF		テーブル型
ON		アップライト型

ボーナス設定

SW	4	5	ボーナス
OFF	OFF		1回目20,000PTS 2回目以降70,000PTS毎
ON			1回目30,000PTS 2回目以降80,000PTS毎
OFF	ON		初回20,000PTSのみ
ON			初回70,000PTSのみ

ゲームの難度

SW	6	7	難度
OFF	OFF		易しい
ON			普通
OFF	ON		難しい
ON			大変難しい

テモ中の音

SW	8	音
OFF		無
ON		有

2. DIP SWITCH No.2 SETTINGS

SW	5	6	7	COIN	PLAY
OFF	OFF	OFF	OFF	1	1
ON				1	2
OFF	ON			1	3
ON				1	4
OFF	OFF	ON	OFF	1	5
ON				1	6
OFF	ON			1	7
ON				2	1
OFF	OFF	OFF	ON	2	3
ON				2	5
OFF	ON			3	1
ON				3	2
OFF	OFF	ON	ON	3	4
ON				4	1
OFF	ON			4	3
ON				VOID	

DIP SWITCH No.2 SETTINGS

1. THE NUMBER OF PLAYER'S LIFE

SW	1	2	NUMBER
OFF	OFF		2
ON			3
OFF	ON		4
ON			7

2. CHANGE OF TABLE/UPRIGHT

SW	3	TYPE
OFF		TABLE
ON		UPRIGHT

3. BONUS LIFE

SW	4	5	BONUS LIFE
OFF	OFF		AT 20,000PTS AND EVERY 70,000PTS THEREAFTER
ON			AT 30,000PTS AND EVERY 80,000PTS THEREAFTER
OFF	ON		AT 20,000PTS ONLY
ON			AT 70,000PTS ONLY

4. DIFFICULTY OF THE GAME

SW	6	7	DIFFICULTY
OFF	OFF		EASY
ON			NORMAL
OFF	ON		DIFFICULT
ON			VERY DIFFICULT

5. SOUND IN ATTRACTIVE MODE

SW	8	SOUND
OFF		OFF
ON		ON



OPERATOR'S MANUAL



© KONAMI 1988

**GRADIUS**  
**GOFERの野望**™  
 やぼう



「GRADIUS II GOFERの野望」は弊社(コナミ)が独自に開発したオリジナル製品であり、著作権、工業所有権、その他の諸権利はコナミ株式会社が所有しております。  
 「VULCAN VENTURE」 is an original game developed by KONAMI Industry Co., Ltd..  
 KONAMI Industry Co., Ltd. reserves all the copyrights, trademarks and other industrial property rights with respect to this game.

Technical Information

- (1) Required Power Capacity  
GND- Vcc 5V9A or more  
GND- (+12V) See the WIRING DIAGRAM
- (2) Output  
R (red) analog, positive  
G (green) analog, positive  
B (blue) analog, positive  
Sync. H-V complexed, negative
- (3) Use the left-hand volume knob on the PCB to adjust sound level. Turn the knob clockwise and it becomes louder.
- (4) Handle with care.

Play Instruction.

- Move your spaceship by using 8-way joystick and destroy enemies with SHOOT button.
- Use MISSILE button to launch missiles after you have obtained the power up feature.
- POWER METER selections are shown on the screen before the game starts. Use joystick and a button to select a combination.

SPEED UP	MISSILE	DOUBLE	LASER	MULTIPLE
SPEED UP	MISSILE	DOUBLE	LASER	MULTIPLE
SPEED UP	SPREAD BOMB	TAIL GUN	LASER	MULTIPLE
SPEED UP	PHOTON TORPEDO	DOUBLE	PULSE	MULTIPLE
SPEED UP	2-WAY	TAIL GUN	PULSE	MULTIPLE

?	SHEILD	FORCE FIELD	Select right or left.
---	--------	-------------	-----------------------


POWER UP

- Destroy the enemies and capture power capsules.
- Press SPECIAL POWER button to obtain features illuminated on power meter.
- You can obtain multiple power up features but you cannot have DOUBLE as well as LASER.

POWER UP FEATURES

- \* SPEED UP — Five speed levels. Travel faster each time.
- \* MISSILE — Press MISSILE button to launch missiles.
- SPREAD BOMB — Destroy the enemies on the ground in a wider range.
- PHOTON TORPEDO — Search and destroy ground enemies.
- 2-WAY — Launch missiles upwards and downwards.

- DOUBLE (ダブル) — ショットボタンで空中の敵を破壊できます。
- TAIL GUN (テイルガン) — 空中の前後方向の敵を破壊できます。
- LASER (レーザー) — ショットボタンでレーザー光線を発射できます。
- RIPPLE (リップル) — 波紋型レーザー。徐々に拡大し、有効範囲が広がります。
- OPTION (オプション) — 分身が付きません。最高4つまで取れません。
- SHIELD (シールド) — 前方のみを防ぐバリアが付きません。
- FORCE FIELD (フォースフィールド) — 全方向を防ぐバリアが付きません。



ディップスイッチ No.1 セット

1. コインスイッチNo.1セット

SW	1	2	3	4	コイン	プレイ
○	OFF	OFF	OFF	OFF	1	1
	ON				1	2
	OFF	ON			1	3
	ON				1	4
	OFF	OFF	ON	OFF	1	5
	ON				1	6
	OFF	ON			1	7
	ON				2	1
	OFF	OFF	OFF	ON	2	3
	ON				2	5
	OFF	ON			3	1
	ON				3	2
	OFF	OFF	ON	ON	3	4
	ON				4	1
	OFF	ON			4	3
	ON					フリープレイ

(注意)フリープレイとはコインを投入せずプレイできる状態をいう。

DIP SWITCH No.1 SETTINGS

1. COIN SWITCH No.1 SETTINGS

SW	1	2	3	4	COIN	PLAY
○	OFF	OFF	OFF	OFF	1	1
	ON				1	2
	OFF	ON			1	3
	ON				1	4
	OFF	OFF	ON	OFF	1	5
	ON				1	6
	OFF	ON			1	7
	ON				2	1
	OFF	OFF	OFF	ON	2	3
	ON				2	5
	OFF	ON			3	1
	ON				3	2
	OFF	OFF	ON	ON	3	4
	ON				4	1
	OFF	ON			4	3
	ON					FREE PLAY

(Note) Free Play : You can play games without coin.

仕様  
A以上  
参照  
は、国内で販売されている、一般的な  
接続可能です。  
Cボード上のLEFTボリュームで  
大きくくなります。RIGHTボリューム

装置のため、運送時などは、取扱い方

プレイヤー機を操作します。  
左からパワーアップボタン、ショット  
ボタンで攻撃開始。  
パワーアップの時のみ使用可能です。  
押ししてもミサイルは出ません。  
にパワーメーター・セレクト画面が

び、ボタン(3種のどれでも可)で決

E	DOUBLE	LASER	OPTION
E	DOUBLE	LASER	OPTION
AD	TAIL GUN	LASER	OPTION
3			
YN	DOUBLE	RIPPLE	OPTION
00			
Y	TAIL GUN	RIPPLE	OPTION

りごとです。

D	FORCE FIELD
---	-------------

どちらか一方です。

敵隊の敵を全て破壊すると「エネルギー  
見られます。「エネルギーカプセル」を  
ワメーターに表示されたパワーアッ  
に黄色く光ります。  
-アップの種類が黄色に光っているとき、  
ボタンを押すと、そのパワーアッププレイ

DOUBLE	LASER	OPTION	?
--------	-------	--------	---

パワーアップをすることは可能です。  
と「LASER」の併用はできません。

種類  
5段階までスピードアップします。

ミサイルボタンで地上の敵を破壊でき  
ます。  
地面に当たると広範囲に爆発。

貫通力のあるミサイル。

地上と天井の2方向に飛ぶミサイル。