


# SIn<sup>®</sup>


## GAME MANUAL

COPYRIGHT 1991

© SUNA ELECTRONICS IND CO., LTD.

## CONTROL PANEL





L

T

### HOW TO PLAY

#### 1. HOW TO ATTACK THE ENEMY

- 1-1. JUMP AND TREAD THEM DOWN
- 1-2. HIT WITH THE DUKES OR THE FEET
  - 1-3. USE 3 KINDS OF WEAPONS AS FOLLOWS;
  - PANEL TO B OR TAKING A NUMBERING
  - PANEL TO B OR B
  - TRUMPET- CHANGE TO WEAPONS OF VARIOUS KINDS

    WHEN A NUMBERING PANEL TO BE TAKED.
  - •WINGS POSSIBLE TO FLY IN THE AIR IN CASE

    OF THE BUTTON FOR JUMP IS PRESSED

    CONTINUOUSLY.

#### 2. THE SCORE OF POINTS

- 2-1. ATTACKING THE ENEMY \$100 OR 200 POINTS
  2-2. KILLING OFF THE ENEMY \$500 POINTS
  2-3. KILLING OFF A BIG BOSS \$3000 POINTS
  2-4. CATCHING ALL SORTS OF ITEMS \$100,300 OR 500 POINTS
- 3. BONUS FOR SCORE

(THE BONUS FOR SCORE IS MARKED EVERYTIME FINISHING EACH STAGES.)

- 3-1. HIT BONUS CONE ENEMY X 500 POINTS
- 3-2. GOLD BONUS: ONE GOLD X200 POINTS
- 3-3. TIME BONUS REMAINING TIME X 100 POINTS

#### 4. BONUS FOR NUMBER OF PLAYER

- 4-1. GOLD SADDED TO ITS AND THEN STORED FITS IN A SAVINGS BOX EVERYTIME CATCHING THE NUMBER OF GOLD (1) OR (5)
- 4-2. THE NUMBER OF PLAYER IS ADDED ONE WHEN GOLD IS STORED MORE THAN TOTAL 50 PIECES.

## DIP SW-A

ITEM	DESCRIPT	ION		1	2	3	4	5	6	7	8
	1 COIN	1 CREDIT	0	OFF	0 F F	OFF				<u> </u>	L
	1 COIN	2 CREDIT		ON	OFF	0 F F					
	, 1 COIN	3 CREDIT		OFF	ON	0 F F					
COIN	1 COIN	4 CREDIT		0 N	ON	0 F F					
4	2 COIN	1 CREDIT		OFF	OFF	0 N					
	3 COIN	1 CREDIT		0 N	OFF	0 N					
	4 COIN	1 CREDIT		0 F F	ON	0 N					
	5 COIN	1 CREDIT		0 N	ON	0 N					
DIFFICULTY	EA8Y	1					OFF	OFF	OFF		
	NORMAL	2	•				ON	OFF	OFF		
		3					OFF	0 N	0 F F		
	DIFFICUL	. T 4					ON	0 N	OFF		
And the state of t			•	<b> </b>				<u> </u>			,
TEST	N O		•							OFF	
	YE8			ļ					·	0 N	
DEMO BOUND	N O		•								OFF
	Y E 8										0 N

## DIP SW-B


ITEM	DESCRIPTI	0 N			1	2	3	4	5	6	7	8
8 CREEN ,	NORMAL			•	0 F F		1		·	<b>.</b>		
REVER8E	REVERSE				O N							
GAME STYLE	UPRIGHT			•		OFF						
	TABLE				1	0 N						
PAIR PLAY	YE8			•			OFF					
(ONLY UPRIGHT)	N O						0 N					
B O N U 8	NO BONUS							0 F F	OFF	OFF		
	10000 01	I L Y		•				0 N	OFF	OFF		
	30000 01	ILY						OFF	ON	OFF		
	50000 01	I L Y	•		1			ON	0 N	0 F F		
	50000. E	ERY	500	000				OFF	OFF	ON		
	100000. EV	ERY	500	000				0 N	OFF	O N		
	100000. EV	ERY	100	000				OFF	0 N	O N		
	200000. EV	ERY	100	0000				0 N	ON	ОИ		
NUMBER OF PLAYERS	······································		3	•				<del></del>	<del> </del>		OFF	0 F
			2								0 N	0 F
			4								OFF	0 N
			5								0 N	0 N

## WIRING DIAGRAM

г

	PARTS SIDE
1	GND
2	GND
3	+ 5 V
4	+ 5 V
5	
6	+12V
	BLANK
	1P START LAMP
	COIN COUNTER
1	SPEAKER (+)
1 -	
12	VIDEO R
13	VIDEO B
I	VIDEO GND
16	COÍN 1
	1P START
	1P UP
	1P DOWN
20	1P LEFT
21	1P RIGHT
22	1P SHOT
23	1P JUMP
24	
25	
26	
27	GND
28	GND
	1 1 1 2 1 3 1 4

┙



by SUN A ELECTRONICS IND