

# NOSTRADAMUS

S e r v i c e M a n u a l

**FACE** CO., LTD.


# JAMMA STANDARD

SOLDER SIDE			PARTS SIDE
GND	A	1	GND
GND	B	2	GND
+5V	C	3	+5V
+5V	D	4	+5V
	E	5	
+12V	F	6	+12V
	H	7	
COIN COUNTER 2	J	8	COIN COUNTER 1
	K	9	
SPEAKER(-)	L	10	SPEAKER(+)
	M	11	
VIDEO GREEN	N	12	VIDEO RED
VIDEO SYNC	P	13	VIDEO BLUE
SERVICE SW	R	14	VIDEO GND
	S	15	TEST SW
COIN SW 2	T	16	COIN SW 1
START SW 2	U	17	START SW 1
2P UP	V	18	1P UP
2P DOWN	W	19	1P DOWN
2P LEFT	X	20	1P LEFT
2P RIGHT	Y	21	1P RIGHT
2P PUSH 1	Z	22	1P PUSH 1
2P PUSH 2	a	23	1P PUSH 2
2P PUSH 3	b	24	1P PUSH 3
	c	25	
	d	26	
GND	e	27	GND
GND	f	28	GND


■ BOARD CONNECTOR  
JAMMA STANDARD

■ CRT MONITOR SCREEN  
VERTICAL SCREEN  
DISPLAY

■ CONTROL PANEL



8-DIRECTION  
LEVER



ENERGY  
CHARGED  
BY PUSHING  
FIRE BUTTON  
E.B.A ENERGY  
CHARGER

■ TWO PEOPLE CAN PLAY  
SIMULTANEOUSLY  
YOU CAN JOIN MID-GAME



## TEST MODES

Test patterns will appear on CRT monitor screen if you put on 2-8 dip switch.  
Furthermore, by pressing service switch, the following modes will appear.

- SWITCH TEST
- DIP SWITCH DISPLAY
- SOUND TEST
- BG CHARACTER TEST
- SPRITE TEST

**FACE** CO., LTD.

1 - 9 - 8 YAYOI-CHO NAKANO-KU TOKYO 164 JAPAN

TEL 03 ( 3 3 7 2 ) 7 7 6 6

FAX 03 ( 3 3 7 2 ) 7 8 5 5