

Pinball Action

		DIP SWITCH A							
		1	2	3	4	5	6	7	8
COIN 1	1 COIN 1 PLAY	OFF	OFF						
	1 COIN 2 PLAY	ON	OFF						
	1 COIN 3 PLAY	OFF	ON						
	1 COIN 6 PLAY	ON	ON						
COIN 2	1 COIN 1 PLAY			OFF	OFF				
	2 COIN 1 PLAY			ON	OFF				
	1 COIN 2 PLAY			OFF	ON				
NO. OF BALLS	1 COIN 3 PLAY			ON	ON				
	3					OFF	OFF		
	4					ON	OFF		
	5					OFF	ON		
TYPE	2					ON	ON		
	COCKTAIL TABLE							OFF	
DEMONSTRATION SOUND	UP RIGHT							ON	
	SOUND								OFF
SOUND	NON SOUND								ON
		DIP SWITCH B							
		1	2	3	4	5	6	7	8
BONUS	70000,200000	OFF	OFF	OFF					
	70000,200000,1000000	ON	OFF	OFF					
	100000	OFF	ON	OFF					
	100000,300000	ON	ON	OFF					
	100000,300000,1000000	OFF	OFF	ON					
	200000	ON	OFF	ON					
	200000,1000000	OFF	ON	ON					
EXTRA	NO	ON	ON	ON					
	EASY				OFF				
DIFFICULTY 1	DIFFICULT				ON				
	EASY					OFF	OFF		
	NORMAL					ON	OFF		
DIFFICULTY 2	DIFFICULT					OFF	ON		
	VERY DIFFICULT					ON	ON		
	NORMAL							OFF	OFF
	EASY							ON	OFF
	DIFFICULT							OFF	ON
	VERY DIFFICULT							ON	ON

PINBALL ACTION

Pinball Action

1 2 3 4 5 6 7 8

85/09/17
PINBALL ACTION

WIRING DIADRAM

SOLID SIDE

PART SIDE

2P BALL START	1	
2P SHAKE	2	2P LEFT
2P RIGHT	3	
	4	
1P BALL START	5	
1P SHAKE	6	1P LEFT
1P RIGHT	7	
	8	
COIN	9	
2P START	10	1P START
GND	11	GND
GND	12	GND
GREEN	13	BLUE
SYNC	14	RED
SPEAKER	15	SPEAKER
+12V	16	+12V
+5V	17	+5V
+5V	18	+5V

Pinball Action