


*** SAURO ***

COMPONENT SIDE		SOLDER SIDE	
+ 5 Vcc	18A	18B	GND
+ 5 Vcc	17A	17B	GND
	16A	16B	+ 12 Vdc
1P MISSILE	15A	15B	1P UP
1P ATTACK	14A	14B	1P DOWN
2P MISSILE	13A	13B	1P LEFT
2P ATTACK	12A	12B	1P RIGHT
2 PLAYERS	11A	11B	2P UP
1 PLAYER	10A	10B	2P DOWN
COIN 2	9A	9B	2P LEFT
COIN 1	8A	8B	2P RIGHT
BLUE	7A	7B	COUNTER ONE
RED	6A	6B	COUNTER TWO
GREEN	5A	5B	
SYNCR0	4A	4B	SPEAKER
+ 12 Vdc	3A	3B	SPEAKER
GND AUDIO	2A	2B	+ 5 Vcc
GND	1A	1B	+ 5 Vcc

DIP SWITCH 5

DIP SWITCH 1

OPTION		8	7	6	5	4	3	2	1
TEST		ON							
PLAY		OFF							
ADVERTISE SOUND	WITH		ON						
	WITHOUT		OFF						
UPRIGHT TABLE				ON					
				OFF					
FREE PLAY COIN PLAY					ON				
					OFF				
GAME DIFFICULTY	VERY EASY					ON	ON		
	EASY					OFF	ON		
	DIFFICULT					ON	OFF		
	VERY DIFFICULT					OFF	OFF		
PROGRESIVE PLAY	CONTINUE							ON	
	NOT CONTINUE							OFF	
STOP * NO STOP									ON
									OFF



* FOR VERIFICATION PURPOSES ONLY, STOP THE PICTURE WITH 11 AND CONTINUE WITH 21.

DIP SWITCH 2

OPTION		8	7	6	5	4	3c	2.	1
LEFT COIN	1 COIN 1 CREDIT	ON	ON						
	2 COIN 1 CREDIT	OFF	ON						
	3 COIN 1 CREDIT	ON	OFF						
	4 COIN 1 CREDIT	OFF	OFF						
RIGHT COIN	1 COIN 2 CREDIT			ON	ON				
	1 COIN 3 CREDIT			OFF	ON				
	1 COIN 4 CREDIT			ON	OFF				
	1 COIN 5 CREDIT			OFF	OFF				
NUMBER OF PLAYERS	2 MEN					ON	ON		
	3 MEN					OFF	ON		
	4 MEN					ON	OFF		
	5 MEN					OFF	OFF		

