

## CONNECTEUR G

COTE COMPOSANTS	COTE SOUDURES
22 N/C	N/C
21 TRIGGER	N/C
20 N/C	N/C
19 N/C	N/C
18 N/C	N/C
17 N/C	N/C
16 N/C	N/C
15 N/C	N/C
14 N/C	N/C
13 N/C	N/C
12 START P1	N/C
11 SERVICE	SLAM SWITCH
10 N/C	N/C
9 N/C	N/C
8 CREDIT P1	N/C
7 N/C	N/C
6 KEY	KEY
5 SPK +	SPK -
4 V.SVNC	N/C
3 V.GREEN	V.BLUE
2 V.RED	V. GROUND
1 GND	GND

## CONNECTEUR T

COTE COMPOSANTS	COTE SOUDURES
18 +5V	+5V
17 +5V	+5V
16 +5V	+5V
15 +5V	+5V
14 N/C	N/C
13 N/C	N/C
12 N/C	N/C
11 N/C	N/C
10 N/C	N/C
9 N/C	N/C
8 N/C	N/C
7 KEY	KEY
6 N/C	N/C
5 OPTIC	N/C
4 GND	GND
3 GND	GND
2 GND	GND
1 GND	GND

## CONNECTEUR H

12 +12V
11 +12V
10 KEY
9 +12V
8 -5V
7 +5V
6 +5V
5 +5V
4 GND
3 GND
2 GND
1 GND

## CONNECTEUR Y

5 SPEAKER -
4 GND
3 GND
2 SPEAKER +
1 N/C