

"TASK FORCE HARRIER" DIP SWITCH INSTRUCTION

DIP SWITCH 1

	1	2	3	4	5	6	7	8	
NUMBER OF SHIP	X	X							3 SHIPS
	O	X							2 SHIPS
	X	O							4 SHIPS
	O	O							5 SHIPS
EXTEND			X	X					1 TIME (200,000PTS)
			O	X					(NIL)
			X	O					2 TIMES (200,000 & 1,000,000)
			O	O					6 TIMES $\begin{pmatrix} 200,000 & 500,000 \\ 1,000,000 & 2,000,000 \\ 3,000,000 & 5,000,000 \end{pmatrix}$
DIFFICULTY					X	X			NORMAL
					O	X			EASY
					X	O			DIFFICULT
					O	O			TOP DIFFICULT
TYPE								X	UP RIGHT TYPE
								O	COCKTAIL TABLE TYPE

DIP SWITCH 1

- 1 NUMBER OF SHIP
- 2 NUMBER OF SHIP
- 3 EXTEND
- 4 EXTEND
- 5 DIFFICULTY
- 6 DIFFICULTY
- 7 NOT USED
- 8 TYPE

DIP SWITCH 2

- 1 COIN CHUTE 1
- 2 COIN CHUTE 1
- 3 COIN CHUTE 1
- 4 COIN CHUTE 2
- 5 COIN CHUTE 2
- 6 COIN CHUTE 2
- 7 DEMO SOUND ON/OFF
- 8 NOT USED

DIP SWITCH 2

	1	2	3	4	5	6	7	8	
COIN CHUTE 1	X	X	X						1 COIN 1 CREDIT
	O	X	X						1 COIN 2 CREDIT
	X	O	X						1 COIN 3 CREDIT
	O	O	X						1 COIN 4 CREDIT
	X	X	O						2 COIN 1 CREDIT
	O	X	O						3 COIN 1 CREDIT
	X	O	O						4 COIN 1 CREDIT
	O	O	O						FREE GAME
COIN CHUTE 2				X	X	X			1 COIN 1 CREDIT
				O	X	X			1 COIN 2 CREDIT
				X	O	X			1 COIN 3 CREDIT
				O	O	X			1 COIN 4 CREDIT
				X	X	O			2 COIN 1 CREDIT
				O	X	O			3 COIN 1 CREDIT
				X	O	O			4 COIN 1 CREDIT
				O	O	O			FREE GAME
DEMO							X		DEMO SOUND ON
							O		DEMO SOUND OFF

O ON
X OFF

CONNECTOR—JAMMA



T. H. HARRISER.

SOLDER SIDE				COMPONENT SIDE	
GND		A	1	GND	
GND		B	2	GND	
+5V		C	3	+5V	
+5V		D	4	+5V	
		E	5		
+12V		F	6	+12V	
		H	7		
		J	8		
COIN COUNTER 2		K	9	COIN COUNTER 1	
SPEAKER (-)		L	10	SPEAKER (+)	
		M	11		
VIDEO (GREEN)		N	12	(RED)	
VIDEO (SYNC)		P	13	(BLUE)	
		R	14	(GND)	
		S	15		
COIN SW /		T	16		
START SW 2		U	17	START SW 1	
2P CONTROL 1 UP		Y	18	1P CONTROL 1 UP	
2P CONTROL 2 DOWN		W	19	1P CONTROL 2 DOWN	
2P CONTROL 3 LEFT		X	20	1P CONTROL 3 LEFT	
2P CONTROL 4 RIGHT		Y	21	1P CONTROL 4 RIGHT	
2P CONTROL 5 PUSH 1		Z	22	1P CONTROL 5 PUSH 1	
2P CONTROL 6 PUSH 2		a	23	1P CONTROL 6 PUSH 2	
		b	24		
		c	25		
		d	26		
GND		e	27	GND	
GND		f	28	GND	



DIP SWITCH 1

1	2	3	4	5	6	7	8	
X	X							3 SHIPS
O	X							2 SHIPS
X	O							4 SHIPS
O	O							5 SHIPS
		X	X					1 TIME (200,000PTS)
			O	X				(NIL)
		X	O					2 TIMES (200,000 & 1,000,000)
			O					6 TIMES (1,000,000, 200,000, 300,000, 400,000, 500,000, 600,000)
				X	X			NORMAL
				O	X			EASY
						X		DIFFICULT
							O	TOP DIFFICULT
							X	UP RIGHT TYPE
							O	COCKTAIL TABLE TYPE

DIP SWITCH 1

- 1 NUMBER OF SHIP
- 2 NUMBER OF SHIP
- 3 EXTEND
- 4 EXTEND
- 5 DIFFICULTY
- 6 DIFFICULTY
- 7 NOT USED
- 8 TYPE

DIP SWITCH 2

- 1 COIN CHUTE 1
- 2 COIN CHUTE 1
- 3 COIN CHUTE 1
- 4 COIN CHUTE 2
- 5 COIN CHUTE 2
- 6 COIN CHUTE 2
- 7 DEMO SOUND ON/OFF
- 8 NOT USED



DIP SWITCH 2

	1	2	3	4	5	6	7	8	
	X	X	X						1 COIN 1 CREDIT
	O	X	X						1 COIN 2 CREDIT
	X	O	X						1 COIN 3 CREDIT
	O	O	X						1 COIN 4 CREDIT
	X	X	O						2 COIN 1 CREDIT
	O	X	O						3 COIN 1 CREDIT
	X	O	O						4 COIN 1 CREDIT
	O	O	O						FREE GAME
				X	X	X			1 COIN 1 CREDIT
				O	X	X			1 COIN 2 CREDIT
				X	O	X			1 COIN 3 CREDIT
				O	O	X			1 COIN 4 CREDIT
				X	X	O			2 COIN 1 CREDIT
				O	X	O			3 COIN 1 CREDIT
				X	O	O			4 COIN 1 CREDIT
				O	O	O			FREE GAME
							X		DEMO SOUND ON
							O		DEMO SOUND OFF

- O ON
- X OFF

CONNECTOR—JAMMA

