

THUNDER & LIGHTNING 2

DIP SW 1

Item	Condition	1	2	3	4	5	6	7	8
DON'T TOUCH									
Direction	Normal		OFF						
	Reverse		ON						
Demo sound	Yes			OFF					
	No			ON					
DON'T TOUCH	Game				OFF				
	Test				ON				
Coin 1	1 COIN 1 PLAY					OFF	OFF		
	1 COIN 2 PLAY					ON			
	2 COIN 1 PLAY					OFF			
	2 COIN 3 PLAY					ON	ON		
Coin 2	1 COIN 1 PLAY							OFF	OFF
	1 COIN 2 PLAY							ON	
	2 COIN 1 PLAY							OFF	
	2 COIN 3 PLAY							ON	ON

DIP SW 2

Item	Condition	1	2	3	4	5	6	7	8
Difficulty	Normal	OFF	OFF						
	Easy	ON							
	Hard	OFF							
	Very Hard	ON	ON						
Ball extend	20,000/Each 50,000			OFF	OFF				
	30,000/Each 60,000			ON					
	20,000/Each 70,000			OFF					
	30,000/Each 90,000			ON	ON				
Player Stock	2					OFF	OFF		
	3					ON			
	4					OFF			
	1					ON	ON		
DON'T TOUCH								OFF	
								ON	
DON'T TOUCH									OFF
									ON

THUNDER & LIGHTNING 2

● JAMMA

SOLDER SIDE	NO.	NO.	PARTS SIDE
GND	A	1	GND
GND	B	2	GND
+5V	C	3	+5V
+5V	D	4	+5V
	E	5	
+12V	F	6	+12V
	H	7	
	J	8	
	K	9	
SPEAKER (-)	L	10	SPEAKER (+)
	M	11	
VIDEO GREEN	N	12	VIDEO RED
VIDEO SYNC	P	13	VIDEO BLUE
SERVICE SW	R	14	VIDEO GND
	S	15	
COIN SW 2	T	16	COIN SW 1
2P START	U	17	1P START
2P UP	V	18	1P UP
2P DOWN	W	19	1P DOWN
2P LEFT	X	20	1P LEFT
2P RIGHT	Y	21	1P RIGHT
2P SW 1 A BUTTON	Z	22	1P SW 1 A BUTTON
	a	23	
	b	24	
	c	25	
	d	26	
GND	e	27	GND
GND	f	28	GND