TWINKLE

DIP SW 1

| SETTING | POSITION | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|------------|----------------|-----|-----|-----|-----|-------|-----|-----|-----|
| DEMO | *SOUND OFF | OFF | | | | | | | |
| SOUND | SOUND ON | ON | | | | | | | |
| COIN/PLAY | *1COIN 1CREDIT | | OFF | OFF | OFF | | | | |
| | 1COIN 2CREDIT | | ON | OFF | OFF | | | | |
| | 2COIN 3CREDIT | | OFF | ON | OFF | | | | |
| | 1COIN 3CREDIT | | ON | ON | OFF | | | | |
| | 2COIN 1CREDIT | | OFF | OFF | ON | 22.00 | | | |
| | 3COIN 1CREDIT | | ON | OFF | ON | | | | |
| | 4COIN 1CREDIT | | OFF | ON | ON | | | | |
| | 5COIN 1CREDIT | - | ON | ON | ON | | | 1 2 | |
| GAME | *LEVEL 4 | | | | | OFF | OFF | OFF | |
| DIFFICULTY | LEVEL 5 | | | | | ON | OFF | OFF | |
| | LEVEL 6 | | | | | OFF | ON | OFF | |
| | LEVEL 7 | | | | | ON | ON | OFF | |
| | LEVEL 8 | | | | | OFF | OFF | ON | |
| | LEVEL 1 | | | | | ON | OFF | ON | |
| | LEVEL 2 | | | | | OFF | ON | ON | |
| | LEVEL 3 | | | | | ON | ON | ON | OPP |
| TEST MODE | *GAME MODE | | | | | | | | OFF |
| | TEST MODE | | | | | | | | ON |