

部品面

Parts Side

Solder Side

半田面

G N D	A	1	G N D
G N D	B	2	G N D
+ 5 V	C	3	+ 5 V
+ 5 V	D	4	+ 5 V
	E	5	
	F	6	
	H	7	COIN COUNTER
COIN 1	J	8	COIN 2
TEST SW	K	9	SERVICE SW
1 P START	L	10	2 P START
1 P LEFT	M	11	1 P RIGHT
1P PUSH 2	N	12	2P PUSH 1
2 P LEFT	P	13	2 P RIGHT
	R	14	
G N D	S	15	G N D
VIDEO RED	T	16	VIDEO GREEN
VIDEO BLUE	U	17	VIDEO SYNC
	V	18	SP (+)
+ 12 V	W	19	+ 12 V
+ 12 V	X	20	+ 12 V
G N D	Y	21	G N D
G N D	Z	22	G N D

スピーカー (-) は G N D につなぐ

Attach Speaker- to Ground