


"VANDYKE"

CONNECTOR CR7E-56DA - 3.96E (HRS) 3.96mm pitch



VANDYKE

DIP SW - LEFTHAND SIDE		1	2	3	4	5	6	7	8
DIFFICULTY	EASY	ON	ON						
	NORMAL	OFF	OFF						
	HARD	ON	OFF						
	HARDEST	OFF	ON						
DEMO SOUND	NECESSARY			OFF					
	NOT NECESSARY			ON					
(NOT USED)					OFF				

DIP SW - RIGHTHAND SIDE		COIN-SW #1			COIN-SW #2				
		1	2	3	4	5	6	7	8
1 COIN 1 PLAY	1 COIN	OFF	OFF	OFF	OFF	OFF	OFF		
	2 PLAYS	ON	OFF	OFF	ON	OFF	OFF		
	3 PLAYS	OFF	ON	OFF	OFF	ON	OFF		
	4 PLAYS	ON	ON	OFF	ON	ON	ON	OFF	
	1 PLAY	OFF	OFF	ON	OFF	OFF	ON	ON	
2 COINS 1 PLAY	1 PLAY	ON	OFF	ON	ON	OFF	ON		
	1 PLAY	OFF	ON	ON	ON	OFF	ON		
4 COINS 1 PLAY	1 PLAY	OFF	ON	ON	OFF	ON	ON		
	1 PLAY	ON	ON	ON	ON	ON	ON		
CONTINUE	YES							OFF	
	NO							ON	
SCREEN DISPLAY	NORMAL (OR REVERSE)								OFF
	REVERSE (OR NORMAL)								ON

COMPONENT SIDE	TERMINAL NO.	SOLDER SIDE
GND	1 A	GND
GND	2 B	GND
+5V	3 C	+5V
+5V	4 D	+5V
	5 E	
+12V	6 F	+12V
ERROR INSERTION	7 H	ERROR INSERTION
PROTECT KEY		PROTECT KEY
	8 J	
SPEAKER (+)	9 K	SPEAKER (-)
	10 L	
	11 M	
VIDEO RED	12 N	VIDEO GREEN
VIDEO BLUE	13 P	VIDEO SYNC
VIDEO GND	14 R	SERVICE SWITCH
	15 S	
COIN SW #1	16 T	COIN SW #2
START SWITCH 1	17 U	START SWITCH 2
1P CONTROL 1 UP	18 V	2P CONTROL 1 UP
1P CONTROL 2 DOWN	19 W	2P CONTROL 2 DOWN
1P CONTROL 3 LEFT	20 X	2P CONTROL 3 LEFT
1P CONTROL 4 RIGHT	21 Y	2P CONTROL 4 RIGHT
1P CONTROL 5 PUSH1	22 Z	2P CONTROL 5 PUSH1
1P CONTROL 6 PUSH2	23 a	2P CONTROL 6 PUSH2
	24 b	
	25 c	
	26 d	
GND	27 e	GND
GND	28 f	GND

AMDDYKES

FANTASY ACTION



ATTACK!



JUMP!

BYWAY JOYSTICK CONTROLS THE PLAYER
PLAYER ATTACKS WITH R-BUTTON
LONG JUMPS FOR LONG PUSH



ITEMS
SHOP

ATTACK
LEVEL UP



AMDDYKES

FANTASY ACTION



SWORD

FOR CLOSE FIGHT
ALSO SHIELDS
FROM ENEMY BULLETS



BOMB

INFLECT
A DAMAGE
ON ENEMIES
ARROUND



MACE

CONTROL WITH
JOYSTICK LEVER



BOOMERANG

PIERCES
THROUGH
ENEMIES AND
RETURNS

