

COLOUR VIDEO GAME "AMBUSH"

FEATURES

1. THE EXCITEMENTS OF ITS TAKE-OFF AND LANDING MANIPULATION
2. 2 SPEAKERS INTERNALLY EQUIPPED WITH STEREO SOUND
3. SCREEN COUPLED WITH RADAR TO ALERT THE PLAYER
4. SCREEN SLIGHTLY SLANTING BACKWARD IN UPRIGHT POSITION FOR PLAYER'S CONVENIENCE

HOW TO PLAY (6 STAGES)

1. TAKE-OFF

PLAYER IS TO PUSH THE SPACECRAFT'S SPEED BUTTON ON TOP OF LEVER TO ROLLING, SWINGING HER LEFT AND RIGHT ON THE RUNWAY FREELY TO INCREASE ITS SPEED BUT SLOWLY AND CAREFULLY NOT TO HIT THE RUNWAY

AT 300 MILES/HR (SPEED DIGITALLY SHOWN ON THE SCREEN), SPACECRAFT TAKES OFF AFTER PLAYER PULLS TOWARD TO HIMSELF THE CONTROL LEVER.

2. BATTLE

PLAYER TO BATTLE FOR 2 MINUTES DESTROYING THE SPIN(GRREN COURED) BY MISSILES, EVADING METEORITES AT THE SAME TIME ALTHOUGH THEY CAN BE DESTROYED.

NOTE THAT OTHER ENEMIES NEED NOT BE ATTACKED TO PROCEED ON THE NEXT SCENE.

3/4. ENCOUNTER WITH UFO

PLAYER ENCOUNTER UFO IN 2 STAGES WITH LIMITED FUEL, WHICH IS INDICATED ON TOP OF LEFT SIDE SCREEN. FIRST, BATTLE WITH SINGLE UFO BY SHOOTING MISSILES(3). AFTERWARDS, WITH UFO IN FORMATION(4).

SCREEN CLEARED WHEN ALL ARE DESTROYED.

5. COMBAT WITH POWERFUL WARSHIPS

PLAYER TO AVOID UNDESTRUCTIBLE METEORITES AND TO DESTROY THE 3 GALACTIC WARSHIPS. PLAYER HAS TO CONTINUOUSLY PUSH THE SPEED BUTTON TO DESTROY THEM AS THEY CAN GO THROUGH METEORITES AT VERY HIGH SPEED WHERE MISSILES CANNOT CATCH THEM UP.

6. FINAL STAGE - LANDING

PLAYER TO SELECT 1 OUT OF 3 RUNWAYS TO LAND THE SPACECRAFT AT THE SPEED OF NOT LESS THAN 250 MILES/HR BUT NOT MORE THAN 350 MILES/HR.

NOTE THAT SPACECRAFT TO CRASH AT THE SPEED BELOW 250 MILES/HR.

GRADE OF PLAYER ON LANDING

ON 8000 FEET RUNWAY	RECRUIT LEVEL
ON 4000 FEET RUNWAY	COMMANDER LEVEL
ON 2000 FEET RUNWAY	OFFICER LEVEL

Ambush?

36p CONNECTOR TERMINAL DIAGRAM

	A	1	B	
+5v				GND
+5v		2		GND
COIN +12v		3		COIN +12v
ACCELERATOR 1 PLAY		4		DOWN 1 PLAY
"SHOOT" 1PLAY		5		UP 1 PLAY
ACCELERATOR 2 PLAY		6		RIGHT 1 PLAY
"SHOOT" 2 PLAY		7		LEFT 1 PLAY
2 PLAY BUTTON		8		"UP" 2 PLAY
1 PLAY BUTTON		9		"DOWN" 2 PLAY
TWO COINS		10		"LEFT" 2 PLAY
ONE COIN		11		"RIGHT" 2 PLAY
BLUE/MONITOR		12		COUNTER
RED/MONITOR		13		COUNTER
GREEN/MONITOR		14		COUNTER
SYNC/MONITOR		15		SPEAKER/RIGHT
SOUND +12v		16		SPEAKER/LEFT
SOUND GND		17		+5v
GND MONITOR		18		+5v

↑
SURFACE SIDE
 (COMPONENTS SIDE)

↑
BACK SIDE
 (SOLDERING SIDE)

DIP SWITCH

SW 1-2 NUMBER OF SHIPS: SW 3-5 COINS-PLAYS

1	2		3	4	5	
OFF	OFF	6 SHIPS	ON	ON	ON	1 COIN 1 PLAY
ON	OFF	5 SHIPS	ON	ON	OFF	1 COIN 2 PLAYS
OFF	ON	4 SHIPS	ON	OFF	ON	1 COIN 3 PLAYS
ON	ON	3 SHIPS	ON	OFF	OFF	1 COIN 4 PLAYS
			OFF	ON	ON	2 COINS 1 PLAY
			OFF	ON	OFF	2 COINS 3 PLAYS
			OFF	OFF	ON	2 COINS 5 PLAYS
			OFF	OFF	OFF	FREE PLAY

- SW6 EASY(ON)-DIFFICULT(OFF) PRELIMINARY
- SW7 POINTS EXTRA SHIP 120,000 (ON)
- SW7 POINTS EXTRA SHIP 80,000 (OFF)
- SW8 TABLE (ON)

Bestückungsseite

Lötseite

	1	
	2	
	3	
Synchron	4	
TV Grün	5	
TV Rot	6	
TV Blau	7	
Münze Ein	8	
	9	
1 P Start	10	
2 P Start	11	
	12	1 P rechts
	13	1 P links
	14	
	15	
	16	
	17	
	18	
	19	
	20	
+5V	21	GND
+5V	22	GND
	23	
	24	
	25	
	26	
	27	
	28	